







AGGANCIARE NEI PUNTI PREVISTI.
HOOK TOGETHER WHERE INDICATED.
ACCROCHER DANS LES POINTS PREVUS.
HAKE DIE TEILE INEINANDER.






PREMERE VERSO IL FONDO.
PUSH DOWN.
PRESSER VERS LE FOND.
HINUNTER DRÜCKEN.



4

RIPETERE LE OPERAZIONI 2-3 SULL'ALTRO LATO.
REPEAT THE OPERATIONS 2-3 ON THE OTHER SIDE.
RÉPÉTER LES OPERATIONS 2-3 DANS L'AUTRE CÔTÉ.
WIEDERHOLEN SIE DEN VORGANG 2-3 AUF DER ANDEREN SEITE.



PER OTTENERE LE MANIGLIE SPINGERE I LEMBI
VERSO L'INTERNO.
PUSH IN THE SHAPED CARDBOARD TO OBTAIN
THE HANDLES.
POUSSEZ VERS L'INTÉRIEUR LE CARTON FACONNÉ
POUR OBTENIR LES POIGNÉES.
DURCH HINEINDRÜCKEN DER VORGEPRÄGTEN
EINGRIFFE IN DEN KARTON, ERHALTEN SIE DEN
TRAGEGRIFF

COPERCHIO - COVER - COUVERCLE - DECKEL

